



DRY, STYLE, SMOOTH AND VOLUMISE
BELISS BIG HAIR 1000



BaByliss®

SALON STYLE 100

DRYING NOZZLE ATTACHMENT

1. Direct the airflow onto the hair and move the airstyler around the head to remove excess moisture pre-styling.

STEP BY STEP

1. Ensure your hair is 80% dry and combed through to remove any tangles. Divide the hair into sections and secure the selected attachment onto the airstyler.

50MM SOFT BRISTLE BRUSH

1. Place the brush underneath the hair section close to the scalp and hold for a few seconds to boost volume at the roots.
2. Move the styler down through the hair and start to rotate the brush away from your head by pressing and holding the rotation button.
3. As you reach the ends of the hair section, continue rotating the brush to roll the ends under.
4. Repeat for each section of hair.

20MM SOFT BRISTLE BRUSH

1. Place the brush head under a section of hair, close to the roots.
2. Slowly move the brush down along the section, towards the ends of the hair. Rotate the appliance slightly to curl the ends under.
3. Repeat for each section of hair.

STRAIGHTENING ATTACHMENT

1. Place the straightening attachment under a section of hair, as close to the roots as possible with the straightening comb pointing away from your head.
2. Pull the hair section taut against the brush head and gently glide the brush through the section of hair.
3. Repeat for each section of hair.



BaByliss®